
STK500v2 USB Programmer



* Use firmware with defined RSTINVERT